

# **VACALL**

---

## ***Operator & Safety Manual***

*Keep this manual with machine at all times.*

***AllVac***

**VA0000S4366**

*Original Issue,  
June 12, 2009*

**PRELIMINARY**

---

**CALIFORNIA PROPOSITION 65  
BATTERY WARNING**

**Battery posts,  
terminals and related  
accessories contain  
lead and lead compounds,  
chemical known to the  
State of California  
to cause cancer and  
reproductive harm.**

**WASH HANDS  
AFTER HANDLING!**

**CALIFORNIA PROPOSITION 65  
EXHAUST WARNING**

**Diesel Engine exhaust and  
some of its constituents  
are known to the State of  
California to cause cancer,  
birth defects and other  
reproductive harm.**

*Vacall is a registered trademark for street sweepers, catch basin  
cleaners, sewer cleaners, attachments and other components  
manufactured and marketed by Gradall Industries, Inc.*

## **REVISION LOG**

June 12, 2009 - A - Original Issue of Manual

## ***Read This First***

---

This manual is a very important tool! Keep it with the machine at all times.

The purpose of this manual is to provide owners, users, operators, lessors, and lessees with the precautions and operating procedures essential for the safe and proper machine operation for its intended purpose.

Due to continuous product improvements, Gradall Industries, Inc. reserves the right to make specification changes without prior notification. Contact Gradall Industries, Inc. for updated information.

## **Operator Qualifications**

---

The operator of the machine must not operate the machine until this manual has been read, training is accomplished and operation of the machine has been completed under the supervision of an experienced and qualified instructor.

Operators of this equipment must possess a valid, applicable driver's license, be in good physical and mental condition. Operator must not be using medication which could impair abilities nor be under the influence of alcohol or any other intoxicant during the work shift.

In addition, the operator must read, understand and comply with instructions contained in the following material furnished with the Vacall.

- This Operator & Safety Manual
- All instructional decals and plates
- AEM Vacuum Excavator Safety Manual
- Any optional equipment instructions furnished

The operator must also read, understand and comply with all applicable Employer, Industry and Governmental rules, standards and regulations.

If any manual is missing or illegible, get a replacement from your employer, distributor, or from Gradall Industries, Inc.

## **Modifications**

---

**Any modification to VacAll products must be approved by Gradall Industries, Inc.**

This product must comply with all safety related bulletins. Contact Gradall Industries, Inc. or the local authorized VacAll representative for information regarding safety-related bulletins which may have been issued for this product.

Gradall Industries, Inc. sends safety related bulletins to the owner of record of this machine. Contact Gradall Industries, Inc. to ensure that the current owner records are updated and accurate.

Gradall Industries, Inc. must be notified immediately in all instances where VacAll products have been involved in an accident involving bodily injury or death of personnel or when damage has occurred to personal property or the VacAll product.

**FOR:**

- Accident Reporting and Product Safety Publications
- Current Owner Updates
- Questions Regarding Product Applications and Safety
- Standards and Regulations Compliance Information
- Questions Regarding Product Modifications

**CONTACT:**

Product Safety and Reliability Department  
Gradall Industries, Inc.  
406 Mill Avenue  
New Philadelphia, OH 44663  
Phone: 330-339-2211  
Toll-Free: 1-800-445-4752

**Other Publications Available**

---

Parts Manual ..... VA0000S4368  
Service Manual ..... VA0000S4367

**This Page Intentionally Left Blank**

---

## TABLE OF CONTENTS

### Revision Log

### Read This First

Operator Qualifications .....	b
Modifications .....	b
Other Publications Available .....	c

### Table of Contents

#### Section 1 - General Safety Practices

1.1 Hazard Classification System .....	1-1
Safety Alert System and Safety Signal Words .....	1-1
1.2 General Precautions .....	1-1
1.3 Operation Safety .....	1-2
Electrical Hazards .....	1-2
Fire/Explosion Hazards .....	1-3
Burn Hazards .....	1-4
Crush Hazards .....	1-5
Slip and Fall Hazard .....	1-7
Tip Over Hazard .....	1-7
Job-Site Hazards .....	1-7
Travel Hazards .....	1-8
High Pressure Hazards .....	1-9
Vacuum Hazards .....	1-11
Chemical Hazards .....	1-12
Sewer Gas Hazard .....	1-12
Chemical Waste Hazard .....	1-12
Biological Hazards .....	1-12
Dust Hazard .....	1-13
Confined Spaces Hazard .....	1-14
1.4 Support Systems .....	1-15
1.5 Personal Protection Equipment .....	1-17

#### Section 2 - Pre-Operation and Controls

2.1 Pre-Operation Checks & Inspection .....	2-1
2.2 Walk-Around Inspection .....	2-1
2.3 Safety Decals .....	2-3
Decal Locations .....	2-3
2.4 Controls & Indicators .....	2-5
Cab Control Box .....	2-5
Main Control Box .....	2-6
Body Controls .....	2-8

#### Section 3 - Operation

3.1 Road Mode to Blower/Pump Mode .....	3-1
---	-----

## **Table of Contents**

---

	Manual Transmission Shift Procedures.....	3-1
3.2	Vacuuming .....	3-2
3.3	Decanting .....	3-13
3.4	Unloading Procedure.....	3-15
	Dumping Load/Raising Debris Body.....	3-15
	Cleaning the Debris Body.....	3-17
3.5	Blower/Pump Mode to Road Mode .....	3-18
	Manual Transmission Shift Procedures.....	3-18
3.6	End Of Shift Shutdown .....	3-19
	Winterizing Procedure .....	3-19

### **Section 4 - Lubrication & Maintenance**

4.1	General.....	4-1
4.2	Daily Preventative Maintenance.....	4-2
4.3	Weekly Preventative Maintenance .....	4-5
4.4	Monthly Preventative Maintenance .....	4-6
4.5	150 Hours Preventative Maintenance .....	4-9
4.6	300 Hours Preventative Maintenance .....	4-10
4.7	1000 Hours Preventative Maintenance .....	4-11
4.8	Semi-Yearly Preventative Maintenance .....	4-12
4.9	Yearly Preventative Maintenance .....	4-13
4.10	Lubrication Points.....	4-14

### **Section 5 - Specifications**

5.1	Product Specifications.....	5-1
	Lubricants .....	5-1
	Hydraulic System .....	5-1
	Transfer Case.....	5-1
	Blower.....	5-1
	Bag Filtration System .....	5-1
	Capscrew Marking and Torque Values .....	5-2

### **Index**

---

## SECTION 1 - GENERAL SAFETY PRACTICES

---

### 1.1 HAZARD CLASSIFICATION SYSTEM

#### Safety Alert System and Safety Signal Words

---



OW00101

**DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



OW0021

**WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



OW0031

**CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



OAN0340

**CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in property damage.

---

### 1.2 GENERAL PRECAUTIONS





OW0021

Before operation, read & understand this manual. Failure to comply with the information in this manual could result in machine damage, property damage, personal injury or death.


## Section 1 - General Safety Practices

### 1.3 OPERATION SAFETY

#### Electrical Hazards



OAN0010



OAL0070

- This machine is not insulated and does not provide protection from contact or being near electrical current.
- **NEVER** operate the unit in an area where overhead power lines, overhead or underground cables, or other power sources may exist without ensuring the appropriate power or utility company de-energizes the lines.
- Always check for power lines before raising boom or debris body.

**Fire/Explosion Hazards**

---



OW0300



OAN0020

- **DO NOT** fill the fuel tank or service the fuel system near an open flame, sparks, smoking materials, or with engine running. Engine fuel is flammable and can cause a fire and/or explosion.

## Section 1 - General Safety Practices

---

### Burn Hazards

---



OAN0030

- Never touch the blower casing or associated piping/accessories after operation.
- Engine coolant is hot and under pressure at operating temperature. The radiator and all lines to heaters of the engine contain hot water or steam and any contact could cause severe burns.
- Check coolant level before heating occurs, and if necessary, only after the engine has been stopped and the filler cap is cool enough to remove with your bare hand. Remove filler cap slowly to relieve pressure.
- Allow components to cool before draining. Do not allow hot oil, coolant or components to contact skin.
- Relieve all pressure in air, oil, fuel or cooling systems before any lines, fittings or related items are disconnected or removed.
- Battery electrolyte contains acid that can cause injury. Avoid contact with skin and eye.

Crush Hazards


Debris Body



OAN0050

- Never leave body raised while vehicle is unattended or while performing maintenance on unit.
- Never work under or near the raised debris body without first securing the prop in the support receptacle located on the underside of the body. (See page 1-15 for details).
- Ensure the debris body is empty before using the prop to support the debris body.

Tailgate




OAN0040

- Never enter the debris body or stand beneath the raised tailgate without first securing the tailgate in the open position with the prop. (See page 1-16 for details).
- Ensure there are no personnel at the rear of the unit when operating the dump system.

## Section 1 - General Safety Practices


---

### General



OAC1250

- Do not operate belt driven components with the shroud doors open or belt guards removed. Cover all external moving parts with adequate guards.
- Stay clear of moving parts while engine is running.
- Do engage the PTO or other driven equipment from underneath the vehicle while engine is running.
- Never attempt to stop, stall or slow moving components with hands, feet, or any other portion of your body.




OAL0080

- Stay clear of rotating parts while engine is running.
- Stop the engine and remove the key before going under the chassis.
- Do not engage the PTO or other driven equipment from underneath the vehicle while engine is running.
- Never attempt to stop, stall or slow rotating components with hands, feet, or any other portion of your body.

### Slip and Fall Hazard

---



OAN0060

- Always maintain 3-point contact using proper hand holds and steps provided when mounting or dismounting. Never grab control levers or steering wheel when mounting or dismounting machine.
- Repair or replace damaged steps and grab handles.
- Keep grab handles, steps, and walkways free of mud, oil, grease and other foreign material. Replace non-skid surface material as required.

### Tip Over Hazard

---

- Always ensure unit is on firm and level ground before operating the dump system. When dumping, raise the body in steps, allowing the material to dump out in a steady flow.
- **DO NOT ALLOW** people and/or vehicles beside debris body while dumping.

### Job-Site Hazards

---

- Always use safety cones.
- Always activate beacons and flashers before job set-up.
- Open manholes and other access openings create risks of trips and falls. Be aware of such locations and do not step in or over them. Ensure manhole covers and other covers are in place prior to leaving the jobsite.
- Be aware of traffic and pedestrians on the job site. Use extreme caution while moving around the vehicle to avoid contact with other moving vehicles. Before stowing the boom or moving the vehicle, be sure pedestrians are clear of the area.


## Section 1 - General Safety Practices

---

### Travel Hazards

---

- Ensure unit is road worthy by performing a pre-trip inspection before driving to and from jobsite.
- Look out for and avoid other personnel, machinery and vehicles in the area. Use a spotter if you **do not** have a clear view.
- **Before moving** be sure of a clear path and **sound horn**.
- When machine is operating or driving on public roadways, **comply with all local, state and federal restrictions**.
- **When driving**, ensure all equipment is properly secured and positioned for maximum visibility and adequate clearances. Know the overall height of the machine.
- **Always check overhead and side clearances** carefully before driving.



- Always wear seat belt.
- **Maintain proper tire pressure** at all times.

### High Pressure Hazards

- Release pressure before attempting to open any door, hatch, hose or tube.
- Do not bend or strike high pressure lines.
- Report any loose or damaged tubes or hoses to mechanics so repairs can be made prior to continued use.

#### Water Pressure



OW0021

**WATER PRESSURE INJURY.** In the event of any waterjet injury:

- Seek medical attention immediately!
- Inform the physician of the cause of the injury.
- Tell the physician what type of waterjet project was being performed at the time of the accident and the source of the water.

Operators using or working around high pressure water systems need to take additional precautions including specialized personal protection equipment. Additional information on high pressure water safety and this information is provided by and available as a wallet card from:

#### WaterJet Technology Association

906 Olive Street, Suite 1200

St Louis, MO 63101-1419

(314) 241-1445

fax (314) 241-1449

e-mail: [wjta@wjta.org](mailto:wjta@wjta.org)

website: [www.wjta.org](http://www.wjta.org)

- Use the handgun wash-down system for final equipment and job-site clean-ups or cleaning debris build-ups on the inside of body.
- The water handgun operates at high pressure. Never point the water handgun at yourself or others.
- Always bleed pressure from the water handgun before disconnection from high pressure connection.

## **Section 1 - General Safety Practices**

---



OW0021

High pressure water.

High pressure water can cause serious injury or death. The handgun operates under high pressure. Never point the handgun at another individual. Severe injury can result from high-pressure water.

Special safety equipment is required when operating the high-pressure handgun. Always wear safety toe shoes or boots (waterproof shoes or boots preferred), coveralls, face shield and safety goggles and gloves (waterproof gloves preferred).

### **Vacuum Hazards**

---

An injury caused by vacuum can be serious. The vacuum must be stopped as quickly as possible at any sign of danger. Seek medical attention immediately.

- Keep vacuum tools and hoses away from face and body. Concentrated vacuum on the body, such as through a hose end, can result in serious injury or death.
- Do not attach hose, pipe or accessories with the vacuum on. The vacuum can trap fingers, hands and feet with enough force and impact to crush or cut.
- Do not use a bare open hose end for vacuuming. A variety of hose and attachments are available to keep the operator clear of the hose opening.

## Section 1 - General Safety Practices

---

### Chemical Hazards

---

#### Hydraulic Fluid



OW0950

- **DO NOT** use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks. Wear appropriate equipment to protect yourself from spraying fluid. If fluid is injected into the skin seek medical attention immediately.
- Stop engine, let the hydraulic oil cool, and relieve trapped pressure before loosening any hydraulic fitting. Hydraulic oil is under enough pressure that it can penetrate the skin.
- **DO NOT** attempt to repair or tighten any hydraulic hoses or fittings while the engine is running or when the hydraulic system is pressurized.

### Sewer Gas Hazard

---

- Do not smoke or have lighted materials in or around sewer lines, drains or catch basins.

### Chemical Waste Hazard

---

- Storm drains, catch basins and sewers may contain harmful chemicals. To prevent contamination and injury, wear chemical resistant gloves, long sleeves, trousers and safety glasses or face shields.
- Seek immediate medical attention if exposure or contamination is suspected.

### Biological Hazards

---

- Germs and other biological hazards are common in sewers, drains and catch basins. Use appropriate personal protective equipment to avoid injury and contamination. Get medical attention for injuries associated with cleaning sewers, drains and catch basins if biological contamination is suspected.

**Dust Hazard**

---



OAC0660

- Repeated or substantial breathing of hazardous dusts, including crystalline silica, could cause fatal or serious respiratory disease including silicosis. Concrete, masonry, many types of rock, and various other materials contain silica sand. California lists respirable crystalline silica as a substance known to cause cancer. Operation of this equipment under certain conditions may generate airborne dust particles that could contain crystalline silica. In those conditions personal protective equipment including an appropriate respirator must be used. If excessive dust is generated, a dust collection or suppression system should also be used during operation.

## ***Section 1 - General Safety Practices***

---


### **Confined Spaces Hazard**

---

Follow all requirements for confined space when servicing. All debris body, large water body and vessels that can be entered are to be considered permit-required confined space as defined by the Occupational Safety and Health Administration (OSHA). The following information is from OSHA 3138-01R 2004. The full document can be obtained from [www.osha.gov](http://www.osha.gov).

### 1.4 SUPPORT SYSTEMS

#### Body Support



OAN0070

When maintenance is performed that requires working under a raised body, the raised EMPTY body must be supported by the body support stands provided. These are supports only; not lifting devices. They must be used in conjunction with the hoist cylinder, not in place of.

Never support a loaded body with the body supports. Never try to remove a hoist cylinder, leaving the body supported by the stands. To use the body support stands:

1. Raise the debris body until there is enough room for the support stands to be turned into place. See page 2-8 for details.
2. Turn the handle of the body support stand counterclockwise until it is in the fully upright position.
3. Lower the debris body until the support stands slide into the support receptacle.

## **Section 1 - General Safety Practices**

---


### **Rear Door Support**



When maintenance or cleaning is to be done inside a body or on the rear door that requires it to remain open, use the rear door support provided.

1. Open tailgate. See page 2-8 for details.
2. Unpin the support and let it fall into place.
3. Lower the tailgate until the support slides into the tailgate support receptacle.

## **1.5 PERSONAL PROTECTION EQUIPMENT**



OAL0560

Wear all the protective clothing and personal safety devices issued to you or called for by job conditions. You may need:

- Hard hat
- Safety shoes
- Safety glasses, goggles or face shield
- Heavy gloves (chemical resistant)
- Hearing protection
- Reflective clothing
- Wet weather gear
- Respirator or filter mask

Wear adequate clothing for the job conditions.

Always know where to get assistance in case of an emergency. Know where to find and how to use a first aid kit and fire extinguisher/fire suppression system.

**This Page Intentionally Left Blank**

---

## SECTION 2 - PRE-OPERATION AND CONTROLS

---

### 2.1 PRE-OPERATION CHECKS & INSPECTION

**Note:** Complete all required maintenance before operating unit.



OW0021

**FALL HAZARD:** Use extreme caution when checking items beyond your normal reach. Use an approved ladder. Failure to comply could result in death or serious injury.

Pre-operation checks & inspections must be performed at beginning of each work shift or at each change of operator. **Contact your local Division of Motor Vehicles for a list of Pre-trip inspections that are recommended in the Commercial Driver's License (CDL) Manual. These inspections should be performed before the inspections on the following pages.**

1. Ensure all Safety decals are legible and in place. Clean or replace as required.
2. Before removing filler caps or fill plugs, wipe all dirt and grease away from the ports. If dirt enters these ports, it can severely reduce component life.
3. Check all fluid levels and refill as needed.

**If service or repairs are required, place "Do Not Operate" tag on cab control box ignition, auxiliary engine control panel and steering wheel of vehicle and remove keys.**

---

### 2.2 WALK-AROUND INSPECTION

**Note:** Complete all required maintenance before operating unit.




OW0021

**FALL HAZARD:** Use extreme caution when checking items beyond your normal reach. Use an approved ladder. Failure to comply could result in death or serious injury.

Walk around inspection must be performed at beginning of each work shift or at each change of operator.

## Section 2 - Pre-Operation and Controls

---



OAQ0010

Begin your walk-around inspection at item 1 as noted below. Continue to your right, checking each item in sequence. **Be sure to check all steps below while parked on level ground with all cylinders in their retracted position.**

INSPECTION NOTE: In addition to any other criteria mentioned, on all components:

- Ensure that there are no loose or missing parts and that all parts are securely fastened.
- Check for visible leaks and excessive wear.
- Inspect all structural members for cracks, excessive corrosion and other damage.

1. Blower -

- Check blower oil level. Be sure to check the level on all sight glasses.

2. Transfer Case -

- Check transfer case oil level. Be sure to check level on sight glass.

3. Tailgate -

- Grease tailgate lube points (12 fittings).

4. Blower Driveline -

- Grease blower shaft lube points.

5. Cyclonic Separator - (Air/Water Separator)

- Check for debris build-up and clean.

6. Hydraulic Tank -

- Check hydraulic tank oil level. Tank sight glass should be half full when cold.


7. Hosing - (not shown)

- Check all hydraulic and water hosing for leaks.

## 2.3 SAFETY DECALS


Ensure all **DANGER, WARNING, CAUTION** and instructional decals are legible and in place. Clean and replace as required.

### Decal Locations



OAQ0020


# Section 2 - Pre-Operation and Controls



OAQ0030

## 2.4 CONTROLS & INDICATORS

### Cab Control Box



0AQ0050


**NOTE:** *Some controls may be optional. Check to see which controls your unit is equipped with.*

1. Pump/Road Mode Selector Knob: Selects either pump mode or road mode. To select the "PUMP MODE", turn knob counterclockwise until in position. To select "ROAD MODE", turn knob clockwise until in position.
2. Blower Mode Selector Knob: Engages/disengages blower. To engage blower, turn knob clockwise to "IN" position. To disengage blower, turn knob counterclockwise to "OUT" position.
3. Blower Mode In Indicator: Indicator light will illuminate when blower mode is activated.
4. Road Mode Out Indicator: Indicator light will illuminate when road mode is switched to pump mode.

## Section 2 - Pre-Operation and Controls

### Main Control Box

#### Main Controls



OAQ0040

**NOTE:** Some controls may be optional. Check to see which controls your unit is equipped with.

1. **Throttle Increase/Decrease:** Switch for controlling the increase/decrease of the throttle. Press and hold switch up to the "INCREASE" position to slowly increase the engine rpm's. Press and hold switch down to the "DECREASE" position to slowly decrease the engine rpm's.
2. **Light Switch:** Switch for turning the control box light on/off. Depress right side side of switch to turn the light "ON". Depress left side of switch to turn light "OFF".
3. **Blower Inlet Vacuum Gauge:** Indicates vacuum (negative pressure) level.


## ***Section 2 - Pre-Operation and Controls***

---

4. Tachometer: Indicates engine rpm.
5. Air Pressure Gauge: Indicates air pressure in the unit.
6. Throttle On/Off: Switch for activating/deactivating the throttle. Press switch up to the "ON" position to activate the throttle. Press switch down to the "OFF" position to deactivate the throttle.
7. Pulsation System On/Off: Switch for activating/deactivating the pulsation system. Press switch up to the "ON" position to activate the pulsation system. Press switch down to the "OFF" position to deactivate the pulsation system.
8. Vacuum Relief Open/Close: Switch for opening/closing the vacuum relief. Press switch up to the "OPEN" position to open the vacuum relief. Press switch down to the "CLOSE" position to close the vacuum relief.
9. Power to Panel On/Off: Switch for activating/deactivating the panel. Press switch up to the "ON" position to activate the panel. Press switch down to the "OFF" position to deactivate the panel.

## Section 2 - Pre-Operation and Controls

### Body Controls




OAQ0060

1. **Tailgate Close:** Push and hold lever in to lower the tailgate.
2. **Tailgate Open:** Pull and hold lever to open the tailgate.
3. **Body Lower:** Push and hold lever in to lower the body.
4. **Body Raise:** Pull and hold lever to raise the body.
5. **Body Vibrator Off:** Push lever in to deactivate the vibrator. This Control is optional and may not be available on all units.
6. **Body Vibrator On:** Pull lever to activate the body vibrator.
7. **Sludge Pump Off:** Push lever in to deactivate the sludge pump. This Control is optional and may not be available on all units. This Control is optional and may not be available on all units.
8. **Sludge Pump On:** Pull lever to activate the sludge pump.

### CAUTION

OAN0340

Make sure to release tailgate/body levers once they have been raised or lowered to their limits. Failure to do so may cause damage to the unit.



**9. Knife Valve Open:** Push lever up to open knife valve.

**10. Knife Valve Close:** Pull lever down to close knife valve.

**This Page Intentionally Left Blank**

---

## **SECTION 3 - OPERATION**

---

### **3.1 ROAD MODE TO BLOWER/PUMP MODE**

These are general instructions for each unit. See the placard inside the cab of your unit for details.

#### **Manual Transmission Shift Procedures**

---

### **CAUTION**

Read instructions before operating. Failure to follow shifting procedure may cause transfer case damage.

OAN0340


To begin operation.

1. Set parking brake.
2. Idle engine.
3. Build air pressure to 90+ psi.
4. Shift transmission to "HIGH RANGE". Place shifter in "REVERSE". Feather clutch out and return to neutral.
5. Locate "PUMP MODE" switch and turn to "PUMP MODE".
6. Rotate "BLOWER" and/or "WATER PUMP" switches to the "IN" position.
7. DO NOT engage the blower without first opening the vacuum relief. This will allow free air passage.
8. With clutch depressed, shift transmission to operating gear according to tag in cab, and slowly release clutch pedal.
9. Select engine speed with throttle control at panel.
10. Refer to the Gear Diagram plates inside the chassis cab for info on running pump mode with manual transmissions.

## Section 3 - Operation


### 3.2 VACUUMING

To activate and operate:



OAAQ0070

1. Make sure the Power switch **(1)** on the front of the power panel is up to the "ON" position to activate the panel controls.



OAAQ0080

2. For units equipped with an air operated vacuum relief valve, make sure the Vacuum Relief switch **(2)** on the front of the power panel is up to the "ON" position.




**THIS ILLUSTRATION IDENTIFIES VALVE LOCATION ONLY. REFER TO INSTRUCTIONS FOR PROPER VALVE POSITIONING.**

3. For units equipped with a manual operated vacuum relief valve, make sure the Vacuum Relief lever (3) near the power panel is turned to the "OPEN" position.


**Note:** If your unit is not equipped with any vacuum relief valves, simply raising the debris body at this step by a foot will supply as much relief as either the air operated or manually operated relief valves would.

## Section 3 - Operation




OAQ0100

4. After removing the Cap Plate (4), connect the vacuum hose to the Vacuum Port (5) near the top of the tailgate and secure with clamps. Unroll the vacuum hose to the material that will be vacuumed.




OAQ0110

5. Press the Engine Throttle On/Off Switch (6) up to the "ON" position to activate the throttle controls from outside of cab.



OAAQ0120


6. Press and hold the Engine Throttle Increase/Decrease Switch (7) up to the "INCREASE" position to bring the engine up to maximum throttle. This increases the amount of vacuum.



OAAQ0130

7. Press the Pulsation System On/Off Switch (6) up to the "ON" position to activate the pulsation system. This should be run at all times while vacuuming dry material so that the filter bags stay clean.

## Section 3 - Operation



OAQ0140

8. For units equipped with an air operated vacuum relief valve, close the vacuum relief valve by pressing the Vacuum Relief switch **(2)** to the "CLOSE" position.



THIS ILLUSTRATION IDENTIFIES VALVE LOCATION ONLY. REFER TO INSTRUCTIONS FOR PROPER VALVE POSITIONING.

9. For units equipped with a manual operated vacuum relief valve, close the vacuum relief valve by turning the Vacuum Relief lever **(3)** to the "CLOSE" position.

### ***Section 3 - Operation***


---

**Note:** If your unit is not equipped with any vacuum relief valves, simply raising the debris body at this step by a foot will supply as much relief as either the air operated or manually operated relief valves would.

10. The unit is now ready to vacuum.

## Section 3 - Operation

### To deactivate:



OAQ0080

1. For units equipped with an air operated vacuum relief valve, press the Vacuum Relief switch (2) on the front of the power panel up to the "OPEN" position.




THIS ILLUSTRATION IDENTIFIES VALVE LOCATION ONLY. REFER TO INSTRUCTIONS FOR PROPER VALVE POSITIONING.

2. For units equipped with a manual operated vacuum relief valve, turn the Vacuum Relief lever (3) near the power panel to the "OPEN" position.


## Section 3 - Operation

**Note:** If your unit is not equipped with any vacuum relief valves, simply raising the debris body at this step by a foot will supply as much relief as either the air operated or manually operated relief valves would.



OAQ0150


3. Press and hold the Engine Throttle switch (7) down to the “DECREASE” position to throttle the engine down as far as it will go. This will not take away all suction from the boom intake tubes.




OAQ0160

4. Press the Engine Throttle On/Off switch (6) to the “OFF” position to deactivate the throttle control from outside of the unit.

## Section 3 - Operation



5. Press the Pulsation System On/Off switch (6) to the "OFF" position to deactivate the pulsation system.



6. For units equipped with an air operated vacuum relief valve, close the vacuum relief valve by pressing the Vacuum Relief switch (2) to the "CLOSE" position.




**THIS ILLUSTRATION IDENTIFIES VALVE LOCATION ONLY. REFER TO INSTRUCTIONS FOR PROPER VALVE POSITIONING.**

7. For units equipped with a manual operated vacuum relief valve, close the vacuum relief valve by turning the Vacuum Relief lever **(3)** to the “CLOSE” position.


**Note:** If your unit is not equipped with any vacuum relief valves, simply raising the debris body at this step by a foot will supply as much relief as either the air operated or manually operated relief valves would.

## Section 3 - Operation



OAQ0180

8. Press the Power to Panel switch (1) down to the "OFF" position to deactivate the panel controls.
9. Shut down the unit. See Page 3-18.




OAQ0100

10. Disconnect and store the vacuum hose. Replace the Cap Plate (4) and Clamp on the Vacuum Porthole (5) on the tailgate.

### 3.3 DECANTING

This function is used to drain excess water from the debris body to make more room for solid waste materials. This function is used only when vacuuming wet materials. This function is used at the job site so that the operator doesn't have to drive to the dump site and come back for more vacuuming.

1. Position the unit on flat level ground with the tailgate near the location that will be used as a liquid dump site.




2. With the unit running in blower mode, remove the Cap Plate (1) from the Knife Valve (2). Unroll the decant lay-flat hose and connect with band clamps to the Knife Valve port (3). Make sure the other end is going into the drain or dump site.

## Section 3 - Operation



3. Turn the Knife Valve handle (4) up to open the Knife Valve.
4. Let the water drain from the unit.



5. Raise the body by pulling the Hoist lever (5). This will allow extra water to drain from the debris body.
6. Lower the body by pushing the Hoist lever (5).
7. Turn the Knife Valve handle (4) down to close the Knife Valve. Roll the decant lay-flat hose up and store.
8. Reattach the Cap Plate (1) to the Knife Valve port (3) and secure.

## **3.4 UNLOADING PROCEDURE**

### **Dumping Load/Raising Debris Body**

The AllVac is designed to dump material collected in the debris body similar to a traditional dump truck.


The unit must be positioned on a solid, level surface able to support the machine.



OW00101

Be sure the unit is on a solid, level surface and that there is sufficient overhead clearance before the debris body is raised.


1. Position the unit so the material being unloaded will not flow back under the unit when the tailgate is opened and the debris body is raised.
2. Start the unit and raise the engine's rpm level as far as it will go.
3. Decant the debris body, see page 3-13.



0AQ0190

4. Open the tailgate by pulling and holding the Tailgate lever (1).

## Section 3 - Operation




OAAQ0200

5. Raise the body by pulling the Hoist lever (2). You may have to rock the debris body by alternating pulling and pushing the lever back and forth. This may help remove debris that has become stuck.

### CAUTION

OAN0340

Make sure to release tailgate/body levers once they have been raised or lowered to their limits. Failure to do so may cause damage to the unit.



OAAQ0210

6. If your unit is equipped with a body vibrator, activate it by pulling the Body Vibrator lever. Deactivate it by pushing the the Body Vibrator lever. This may help remove debris that has become stuck.
7. Raise the body support safety stands. See Page 1-15.
8. Secure the tailgate using the tailgate props. See Page 1-16.
9. Clean the debris body. See below.

---

## **Cleaning the Debris Body**

---

1. Make sure that the tailgate is secured using the tailgate props. See Page 1-16.
2. With the body in the raised position, wash out the entire debris body with a hose. Start at the upper front corner and work downward and toward the rear of the body. Change sides and repeat the procedure. **Note:** *If the unit is to be used immediately after dumping, then it is necessary to clean only the tailgate seal area.*
3. Wash out the sludge pump attached to the tailgate if equipped.
4. Raise the tailgate to remove the tailgate props and lower the tailgate by pushing the Tailgate lever (1).
5. Raise the debris body enough to release/store the body support safety stands.

### **CAUTION**

OAN0340

Attempting to lower the debris body without releasing/storing the body support safety stands first will cause serious machine damage.

6. Lower the body by pushing the Hoist lever (2) until the body is in the fully lowered position.

### **CAUTION**

OAN0340

When the debris body reaches the fully lowered position, IMMEDIATELY release Hoist lever. Failure to do so can cause machine damage.

## Section 3 - Operation

---

### 3.5 BLOWER/PUMP MODE TO ROAD MODE

These are general instructions for each unit. See the placard inside the cab of your unit for details.

#### Manual Transmission Shift Procedures

---

To end operation.

1. Adjust engine rpm throttle control to idle.
2. Depress clutch. Wait one (1) minute before shifting.

#### **CAUTION**

OAN0340

Before shifting from blower mode to road mode, disengage the transmission and allow one (1) minute for the drivelines to stop turning. Failure to do so will CAUSE TRANSFER CASE DAMAGE.

3. With clutch depressed. Switch "WATER PUMP" and/or "BLOWER" to the "OUT" position.
4. With clutch depressed, place mode switch in "ROAD MODE" position.

### **3.6 END OF SHIFT SHUTDOWN**

Shutting down the unit at the end of a shift consists of completely draining the water system and opening the debris body to allow air to circulate through it.

1. Be sure the unit is thoroughly cleaned as described on Page 3-15.
2. If the unit is to be stored longer than overnight, the tailgate should be propped open with the rear door support and the debris body partially raised and blocked.
3. Perform suggested maintenance as described in the service manual.

### **Winterizing Procedure**

---

It is important that the water system and debris body be free of water when the AllJetVac is to be stored in an area where the ambient air temperature may fall below 32° F (0° C). Failure to do so may result in shortened component life or component failure.

1. Clean and dry the debris body.
2. Check all fluid levels and lubricate the unit.

**This Page Intentionally Left Blank**

## **SECTION 4 - LUBRICATION & MAINTENANCE**

---

### **4.1 GENERAL**

Careful attention to proper preventative maintenance as described in this section will insure and extend trouble free operation of the unit. Particular attention to correct lubrication of the unit, routine cleaning, and maintenance of the hydraulic system are the most vital areas of preventative maintenance required. The objective of preventative maintenance is to anticipate and prevent operation difficulties before they require extended down time for costly repairs.

Prepare and adhere to a maintenance schedule. Keep detailed records of all maintenance performed. Regularly inspect operating and maintenance records for deviations from normal operating conditions. Analyze the records for indications of potential trouble.

**Note:** *This section provides general operator lubrication and maintenance information. Refer to Service Manual for detailed maintenance, lubrication and service information.*

## Section 4 - Lubrication & Maintenance

---

### 4.2 DAILY PREVENTATIVE MAINTENANCE

Each day perform the following maintenance:



OW0021

Never enter the AllJetVac body until the blower is disengaged and the truck is off with the keys removed and “Do Not Operate” tags are on the unit. Before entering the body, secure tailgate prop in locked position.

#### 1. Inspection

Perform the pre-operational inspection described in the Operator & Safety manual.

#### 2. Daily Cleaning:

- a. Raise the tailgate and secure with prop.
- b. Raise the debris body and secure with prop.
- c. Clean the inside of the debris body.
- d. Check to make sure the debris body float ball is clear of debris.
- e. Leave the debris body and tailgate raised and open to displace the leftover moisture.
- f. Drain water from hose on tailgate sump.
- g. After the cleaning is completed, start the engine, engage the blower fan and run the unit for a short time to remove moisture from the body. Note: Drain water tank when the ambient temperature is below 32°F (0°C).

**3. Checking Fluid Level** – When checking the fluid level in the hydraulic tank and the blower insure that all cylinders are in their retracted position. The fluid level sight glasses should be half covered. If low, fill the hydraulic tank with hydraulic fluid or the blower with oil as specified in Specifications section. After greasing the blower drive line ensure it rotates freely. Note: When checking the fluid level note any frequent or sudden loss of fluid. This could indicate leakage, which must be traced and corrected to avert equipment failure and possible damage to components.

**4. Engine Oil Level** – Check the engine oil level daily. Add the proper oil as required to maintain the proper oil level. Also, inspect engine and components for leaks.

**5. Cooling System** – Check coolant level daily if coolant is low. Fill to the proper level with soft water or antifreeze. DO NOT OVERFILL. If coolant is repeatedly low, check for leaks.

**6. Drive Belts** – Check belts for proper tension, cracks or fraying on a daily basis.

## ***Section 4 - Lubrication & Maintenance***

---

- 7. Fuel Tank** – Keep fuel tank full to reduce condensation. Use only recommended grade of fuel. Refer to Engine Manual.
- 8. Power Take Off** – Refer to the clutch manual for lubrication and adjustment recommendations.
- 9. Vacuum Pump Oil** – Check level daily. Maintain oil level in center of all sight glasses. If oil level is repeatedly low, consult your vacuum pump manual. Use only recommended lubricants in the vacuum pump. Consult lube chart.
- 10. Hydraulic Oil** – Check daily.
- 11. Pulsation Air Manifold** – Clean daily.
- 12. Float Ball & Cage** – Clean and inspect the float ball for dents, holes and looseness. Clean and inspect the cage for damage or missing pins. Repair or replace as required.

**Note:** On 27" Hg. machines, a rubber seal is provided to ensure a perfect seal. It is most important to check to make sure it is in place and clean everytime you dump.

- 13. Filter Bags** – Check for dust accumulation on the tubesheet or blowpipes. Inspect the top of the bags at the snap ring by lifting cages one at a time. Replace any faulty bags.
- 14. Transfer Case** – Check transfer case oil level daily.
- 15. Air Cannon (Bag Cleaning)** – Drain any accumulated moisture daily to ensure only dry air enters the baghouse. The drain valve is located at the bottom of the cannon.
- 16. Debris Body** – Clean and inspect for cracking, leaks or wear. Repair as required.
- 17. Tailgate & Gasket** – Clean and inspect the gasket for cuts, cracks, wear or looseness. Clean and inspect the tailgate for cracks, leaks or wear. Repair or replace as required.
- 18. Twin Cy-Clean Separators** – Clean and inspect the separators for cracks, leaks or wear. Check the seals for leaks and check the clamps on the doors to make sure they close tightly.
- 19. Baghouse** – Clean and inspect for cracks, cuts or wear. Repair or replace as required.
- 20. Tailgate latches & Hinges** – Lubricate the tailgate latches at the grease fittings and visually inspect the hinges and lock areas for wear or other mechanical problems. Repair or replace as needed.
- 21. Dump Body Hinge** – Grease the body hinge at the rear of the unit at all the grease fittings. Visually inspect the hinges and pins for damage or wear. Repair or replace as required.

## ***Section 4 - Lubrication & Maintenance***

---

- 22. Body Lift Cylinder** – Grease the body hoist cylinder pivot points at the grease fittings. Visually inspect the pivot points for cracks or wear and the cylinder, itself, for seal leakage or physical damage.
- 23. Clean Out Doors** – Clean and inspect the baghouse and separator doors for gasket damage. Check the door latches and hinges for wear or damage. Check the door adjustment to ensure proper sealing to the body. Repair or replace as required.
- 24. Baghouse Top Doors** – Clean and inspect the baghouse door for gasket damage and/or leaks. Check the hinges and locks for damage or wear. Repair or replace as required.

**4.3 WEEKLY PREVENTATIVE MAINTENANCE**

1. **Battery** – Maintain proper fluid level.
2. **Check Air Access Areas** – Check all intake hoses, nozzles, and deflectors for wear. . Also check for tight connections between intake couplers, nozzles, ball joints, etc. Air leaks will reduce the efficiency of the blower.
3. **Engine Mount Bolts** – Check all engine mounting bolts for tightness. Also check all slide and adjustment bolts.
4. **Vacuum Relief Valves** – Check relief valves weekly by inserting a hammer handle into the opening at the bottom of the valves. Use inward pressure on the spring to ensure valves open and close without sticking or binding.

## **Section 4 - Lubrication & Maintenance**

---

### **4.4 MONTHLY PREVENTATIVE MAINTENANCE**

- 1. Air Cleaner** – Remove the element and clean with compressed air at a low pressure.
- 2. Electrical System**– Check electrical wiring and insulation for frays, breaks, corrosion, and loose connections.
- 3. Body Hoist**
  - a. Inspect upper and lower trunnion ends of cylinder, at cylinder and lifting lever cross shafts, at frame, at valve and at pump.
  - b. Inspect all hose lines for damage and hose ends for tightness
  - c. Check valve control for proper shifting.
  - d. Check cylinder packing (a light film of fluid on the piston rod is acceptable)
  - e. Check the mounting bolts for loosening.
  - f. Check the pins for holes and/or wear.

#### **4. Intake Hose**

Intake hoses are made of rubber and fabric and wear should be expected. This wear can be kept to a minimum by employing a few good operation and maintenance practices.

- a. Inspect the hose frequently to determine where the most wear is occurring.
  - b. Rotate the hose periodically to reduce the wear in one spot. Rotating the hose 180 degrees, 90 degrees, and end over end periodically will improve the life.
  - c. Minor cracks, punctures, and other leaks should be repaired as soon as they are detected to prevent enlarging to a point where they cannot be repaired.
- 5. HTD Belt Vacuum Pump Drive** – Inspect belt for wear, cracks or fraying. Check sheave and bushing bolts for tightness. Inspect guide rings on sheaves. Make sure they are not loose or bent. Check pulley alignment and belt adjustments, as recommended.
- 6. Shift Tower Indicator Lights** – Check shift tower indicator lights monthly to make sure they are working. Repair or replace as required.

### 7. Hydraulic System Service

#### Contamination

Many hydraulic problems may be traced directly to the fluid. It is important that all foreign matter be kept from the hydraulic fluid. Invisible quantities of abrasive type contamination may cause serious pump wear, malfunctioning of pumps and valves, and sludge accumulations within the system in relatively short periods of time. It is also essential that moisture and water be kept from the hydraulic fluids and system.

#### Commercial Hydraulic Fluid Testing

Hydraulic fluid samples should be taken periodically for laboratory analysis. The actual sampling method is critical. It should be done based on ANSI Standard B93.19M(R1980). This standard is available from the National Fluid Power Association, 3333 N. Mayfair Rd, Milwaukee, WI 53222

Samples should be taken from the center of the reservoir when the fluid is at operating temperature and placed in a clean, dry, glass bottle with a non-shedding, screw-on cap. The bottle should be labeled with the date, type of fluid, and model and serial number of the machine.

Two identical samples should be taken. One for laboratory analysis and one for your own preliminary analysis while you are waiting for the lab report.

We recommend the use of commercial laboratory services for analysis of routine fluid samples taken on a regularly scheduled basis. The most important analysis are particle count, Spectro-chemical analysis, water content, and viscosity.

#### In House Hydraulic Fluid Testing

After your sample has been allowed to stand for 20 to 30 minutes to eliminate all air bubbles, hold the bottle up to the light to check for debris in the fluid and also check whether the fluid is clear or cloudy.

Any visible debris is an indication of a severe solid contamination problem, the source of which must be located and corrected immediately. Common sources of this kind of contamination may be component wear, unsealed reservoir cover, or dirty air breather filters.

If the sample is the least bit "cloudy" it may be an indication of water contamination, the source of which must be located and corrected immediately. Common sources are inadequate outdoor storage, unsealed reservoir covers or condensation.

A "Blotter Spot Test" may also be performed to test for oxidation. Place a drop of fluid on a piece of white blotter paper (National Fluid Power Association P/N 102480).


**Note:** *The blotter test will provide an indication that a more complete test may be necessary.*

- a. If the blotter remains colorless or develops only a light yellow ring, oxidation is under control.
- b. If color develops but is uniform throughout, the fluid is still serviceable but should be checked for correct additive content.

## Section 4 - Lubrication & Maintenance

---

- c. If the sample shows distinct rings, the fluid should be changed.
- d. If a distinct dark spot remains in the middle, but a lighter color fluid migrates outward in the blotter paper the fluid is about to dump sludge or other by-products into the system. The time for replacement of this fluid has already passed.



MAN0170

**4.5 150 HOURS PREVENTATIVE MAINTENANCE**

- 1. Engine Oil Level** – Check Change the oil approximately every 150 hours.
- 2. Lube Oil Filter** – Check the oil filter approximately every 150 hours. Rplace as required.
- 3. Air Compressor Filter Element** – Check the air compressor filter approximately every 150 hours. Rplace as required.

## ***Section 4 - Lubrication & Maintenance***

---

### **4.6 300 HOURS PREVENTATIVE MAINTENANCE**

1. **Fuel Filter** – Change filter every 300 hours or anytime the fuel system becomes contaminated.

**4.7 1000 HOURS PREVENTATIVE MAINTENANCE**

1. **Cooling System** – Flush and clean cooling system every 1000 hours. Refill with soft water and a high quality antifreeze.

## **Section 4 - Lubrication & Maintenance**

---

### **4.8 SEMI-YEARLY PREVENTATIVE MAINTENANCE**

- 1. Vacuum Pump Oil** – Change the vacuum pump oil every six months under normal service or more frequently, if needed.
- 2. Hydraulic Oil** – Change semi-annually to ensure the long life of all hydraulic components. Change the hydraulic oil anytime it becomes contaminated.
- 3. Hydraulic Return Filter** – Replace filter every six months or anytime the hydraulic oil is changed.
- 4. Hydraulic Suction Filter** – Replace filter every six months or if screen type, remove and clean.
- 5. Vacuum Relief Valves** – Remove, disassemble and clean the relief valves. See manufacturer's recommendation in the parts section of the manual. Anytime the relief valves have been assembled, they have to be calibrated.

**Note:** On 27" Hg. machines there are no relief valves provided.

- 6. Air Dryer/Heater** – Service air dryer/heater every six months. See manufacturer's manual in parts section.

## **4.9 YEARLY PREVENTATIVE MAINTENANCE**

### **1. Flushing Hydraulic System**

- a. Annually drain all fluid from the hydraulic tank. Drain the hydraulic fluid reservoir by removing the drain plug.
- b. Fill the hydraulic tank with fresh fluid as specified in the Specifications section.
- c. Start the Vacall engine and operate all the hydraulic functions as described in the Operator's Manual. Leave all the hydraulic cylinders in the retracted position and shut down the unit.
- d. Recheck the fluid level and add fluid as necessary to bring the level to half way in the sight gauge.
- e. Replace the hydraulic tank air breather.

**2. Air Cleaner** – Replace annually or more if needed. Refer to Engine Manual.

**3. Drive Belts** – Replace or repair drive belts annually or as needed.

### **4. Seasonal Storage**


If the Vacall is going to be inactive for long periods of time, or stored, take the following steps to avoid corrosion in the body and air chamber.

- a. Steam clean the inside of the body.
- b. Repaint with a good primer such as Rustoleum to prevent any corrosive action due to moisture.
- c. Rotate the blower monthly by hand if needed.

## Section 4 - Lubrication & Maintenance

### 4.10 LUBRICATION POINTS

#### LUBRICATION CHART USE STANDARD LITHIUM GREASE



SEE CHASSIS OWNERS MANUAL FOR LOCATION, TYPE, AND FREQUENCY FOR CHASSIS LUBRICATION.

- BLOWER OIL - TEXACO MEROPA 220 OR EQUAL
- DANA SPICER TRANSFER CASE OIL - URSA 50 WT OR EQUAL
- OMSI TRANSFER CASE OIL - DEXRON III OR EQUAL
- HYDRAULIC OIL - MOBILE FLUID 424

OAC00260

SOME ITEMS SHOWN MAY BE OPTIONAL

---

## SECTION 5 - SPECIFICATIONS

---

### 5.1 PRODUCT SPECIFICATIONS

---

#### Lubricants

---

Grease..... Multiservice Lithium Based (quantity grade)

#### Hydraulic System

---

##### (Approximate capacity)

Entire System .....40 gallons (151.42 liters)

Main Reservoir .....31 gallons (117.35 liters)

Oil ..... Mobil 424 or equivalent

System pressure settings ..... Main Valve - 2000 psi

#### Transfer Case

---

##### Omsi

Capacity ..... See Transfer Case Owner's Manual

Type of Oil ..... Dexron III or equal

#### Blower

---

Gear Box Capacity ..... See Blower Owner's Manual

Drive End Capacity..... See Blower Owner's Manual

Type of Oil ..... Texaco Meropa 220 or equal

\*Check sight glass after filling. Oil should be at half level on sight glass.

#### Bag Filtration System

---

Number of Bags ..... 64

Number of Screens ..... 64

Bag Size & Type .....Varies. Check your unit to make sure.

Screen Size & Type .....Varies. Check your unit to make sure.





## Section 5 - Specifications

**CAUTION**

OAN0340

Do not use engine oil, automatic transmission fluid (ATF), or add diesel fuel or kerosene to the hydraulic fluid. The service life of all hydraulic system components may be adversely affected.

### Capcrew Marking and Torque Values

Usage	Much Used	Much Used	Used at Times	Used at Times
Capcrew Diameter & Minimum Tensile Strength PSI	To 1/2-69,000	To 3/4-120,000	To 5/8-140,000	150,000
	To 3/4-64,000	To 1-115,000	To 3/4-133,000	
Quality of Mat'l	Indeterminate	Min. Commercial	Med. Commercial	Best Commercial
SAE Grade Number	1 or 2	5	6 or 7	8
<b>CAPSCREW HEAD MARKINGS</b>				
Manufacturer's marks may vary. These are all SAE Grade 5 (3-line).				
				
<b>Capcrew Body Size (Inches) - (Thread)</b>	<b>Torque Ft-Lb (kg m)</b>	<b>Torque Ft-Lb (kg m)</b>	<b>Torque Ft-Lb (kg m)</b>	<b>Torque Ft-Lb (kg m)</b>
1/4 - 20	5 (0.69)	8 (1.11)	10 (1.38)	12 (1.66)
- 28	(0.83)	10 (1.38)	17 (2.35)	14 (1.94)
5/16 - 18	11 (1.52)	17 (2.35)	19 (2.63)	24 (3.32)
- 24	13 (1.80)	19 (2.63)		27 (3.73)
3/8 - 16	18 (2.49)	31 (4.29)	34 (4.70)	44 (6.09)
- 24	20 (2.77)	35 (4.84)		49 (6.78)
7/16 - 14	28 (3.81)	49 (6.78)	55 (7.61)	70 (9.68)
- 20	30 (4.15)	55 (7.61)		78 (10.79)
1/2 - 13	39 (5.39)	75 (10.37)	85 (11.76)	105 (14.52)
- 20	41 (5.67)	85 (11.76)		120 (16.60)
9/16 - 12	51 (7.05)	110 (15.21)	120 (16.60)	155 (21.44)
- 18	55 (7.60)	120 (16.60)		170 (23.51)
5/8 - 11	83 (11.48)	150 (20.75)	167 (23.10)	210 (29.04)
- 18	95 (13.14)	170 (23.51)		240 (33.19)
3/4 - 10	105 (14.52)	270 (37.34)	280 (38.72)	375 (51.86)
- 16	115 (15.90)	295 (40.80)		420 (58.09)
7/8 - 9	160 (22.13)	395 (54.63)	440 (60.85)	605 (83.67)
- 14	175 (24.20)	435 (60.16)		675 (93.35)
1 - 8	235 (32.50)	590 (81.60)	660 (91.28)	910 (125.85)
- 14	250 (34.58)	660 (91.28)		990 (136.92)

MAN0340

#### Notes:

1. Always use the torque values listed above when specific torque values are not available.
2. The above is based on use of clean, dry threads.
3. Reduce torque by 10% when engine oil is used as a lubricant.
4. Reduce torque by 20% if new plated capscrows are used.

<b>Numerics</b>	
1000 Hours Maintenance	
Cooling System.....	4-11
150 Hours Maintenance	
Air Compressor Filter Element....	4-9
Engine Oil Level.....	4-9
Lube Oil Filter.....	4-9
300 Hours Maintenance	
Fule Filter.....	4-10
<b>B</b>	
Bag Filtration System .....	5-1
Biological Hazards.....	1-12
Blower .....	5-1
Burn Hazards .....	1-4
<b>C</b>	
Chemical Hazards .....	1-12
Chemical Waste Hazard.....	1-12
Controls & Indicators .....	2-5
Crush Hazards .....	1-5
<b>D</b>	
Daily Maintenance.....	4-2
Air Cannon (Bag Cleaning).....	4-3
Baghouse.....	4-3
Baghouse Top Doors.....	4-4
Body Lift Cylinder.....	4-4
Checking Fluid Level.....	4-2
Clean Out Doors.....	4-4
Cooling System.....	4-2
Debris Body .....	4-3
Drive Belts.....	4-2
Dump Body Hinge.....	4-3
Engine Oil Level.....	4-2
Filter Bags.....	4-3
Float Ball & Cage.....	4-3
Fuel Tank.....	4-3
General Cleaning.....	4-2
Hydraulic Oil.....	4-3
Inspection.....	4-2
Power Take Off.....	4-3
Pulsation Air Manifold .....	4-3
Tailgate & Gasket .....	4-3
Tailgate latches & Hinges .....	4-3
Transfer Case.....	4-3
Twin Cy-Clean Separators .....	4-3
Vacuum Pump Oil.....	4-3
Decals .....	2-3
Dust Hazard .....	1-13
<b>E</b>	
Electrical Hazards .....	1-2
<b>F</b>	
Fire/Explosion Hazards.....	1-3
<b>H</b>	
High Pressure Hazards.....	1-9
Hydraulic System .....	5-1
<b>J</b>	
Job-Site Hazards .....	1-7
<b>L</b>	
Lubricants .....	5-1
Lubrication & Maintenance .....	4-1
Lubrication Points .....	4-14
<b>M</b>	
Monthly Maintenance.....	4-6
Air Cleaner.....	4-6
Body Hoist .....	4-6
Electrical System .....	4-6
HTD Belt Vacuum Pump Drive ...	4-6
Hydraulic System.....	4-7
Intake Hose .....	4-6
Shift Tower Indicator Lights .....	4-6
<b>P</b>	
Personal Protection Equipment .....	1-17
Pre-Operation and Controls .....	2-1
Pre-Operation Checks .....	2-1
<b>S</b>	
Safety Practices .....	1-1
Safety Signal Words .....	1-1
Semi-Yearly Maintenance	
Air Dryer/Heater.....	4-12

# **Index**

---

Hydraulic Oil..... 4-12  
Hydraulic Return Filter ..... 4-12  
Hydraulic Suction Filter ..... 4-12  
Vacuum Pump Oil ..... 4-12  
Vacuum Relief Valves ..... 4-12  
Sewer Gas Hazard ..... 1-12  
Slip and Fall Hazard ..... 1-7  
Specifications ..... 5-1

## **T**

Tip Over Hazard ..... 1-7  
Transfer Case..... 5-1  
Travel Hazards ..... 1-8

## **W**

Weekly Maintenance ..... 4-5  
Air Access Areas..... 4-5  
Battery..... 4-5  
Engine Mount Bolts..... 4-5  
Vacuum Relief Valves ..... 4-5

## **Y**

Yearly Maintenance..... 4-13  
Air Cleaner ..... 4-13  
Drive Belts..... 4-13  
Flushing Hydraulic System..... 4-13  
Seasonal Storage..... 4-13



# **VACALL**

*Gradall Industries, Inc.*

*406 Mill Ave SW*

*New Philadelphia OH. 44663*

*USA*

*Phone: (330) 339-2211*

*Customer Support Toll Free: (800) 445-4752*

*Fax: (330) 339-3579*

---